2024/02/15 22:39 1/15 Timer Editor


Inhaltsverzeichnis

Timer Editor	3
Explanation of the keys	3
Editor Explanation	
Date setting	
Recording mode	6
Record	6
Blocked	6
Zap & record	6
Zap	
Setting the start & End time	
Adjustment of Prepad & Postpad	7
After event setting	8
Repeat settings	g
Record path setting	
Setting the search	
Delete settings	

2024/02/15 22:39 3/15 Timer Editor

Timer Editor

These settings are structured identically in the Guide View, Overview view, Grid view and Next event view.



Explanation of the keys



Editor Explanation

The following screenshots show the various keys of the respective fields, depending on where you are.




The blue framed text shows which setting is explained below the screenshot.



The VPS and EPG function is explained HERE in detail.

Show Name




The framed field shows the title of the program to be recorded. This can be edited with OK.



Channel Selection

Printed on 2024/02/15 22:39 https://www.nayal.de/


2024/02/15 22:39 5/15 Timer Editor



The framed field indicates the station for the recording. With the keys the channel selection be changed.




Date setting



The framed box indicates the scheduled date of recording. The date can be edited with the .



Recording mode



With or or the mode of recording can be changed. The following options are available:

Record

The program is recorded

Blocked

The program will not be recorded

Zap & record

Switches to the recording station and the program is recorded


Zap

It is only switched to the recording station without recording

Remind

A so-called M-Timer is created and a reminder is displayed at the set start of the show


Setting the start & End time




The framed box indicates the scheduled start time of the recording.

The time can be edited with the keys. This also applies to the **end times**.


Adjustment of Prepad & Postpad





After event setting


2024/02/15 22:39 9/15 Timer Editor




With you can set what the Vu+ should do after the recording. The following options are available:

Auto > None > Standby > Deep Standby

Repeat settings






Record path setting




With the (PVR button) the name of the program can be taken over from the first field.



Alternatively, the folder for saving the recording can be selected with OK.

Bookmarks can also be selected with the \bigcirc key. These are identical to the bookmarks managed by the VTi.




It is also possible to select the directory marked with the cursor by pressing the key or you can select a directory from the movie list.

Setting the search

With the key you can switch to Search view. Unless a search request has been created for the timer, this field cannot be edited.


2024/02/15 22:39 13/15 Timer Editor



Delete settings

Delete after hours: The recording will be deleted after a specified time. This routine is called up once an hour and deletes the recordings after the set expiry time.

Delete when there is insufficient space: The recording is automatically deleted when there is no more space on the hard drive (currently hard coded to 15GB)



File Name

Use the left and right keys to select which suffix should be added to the recording name. The options are:

- vu+ standard
- Name
- Name + Description
- Name + Timestamp
- Name + Description or Time
- Name + Description + Time
- Name + Time + Description





If you have not selected "vu+ default values" in a search or in the global settings, the recording will be renamed after the end of the recording. If a recording with the same name already exists, the newer one is given the suffix "-2", "-3", etc.

From:

https://www.nayal.de/ -

Permanent link:

https://www.nayal.de/doku.php/en:timereditor

Last update: 2024/01/14 19:39



2024/02/15 22:39 15/15 Timer Editor