Inhaltsverzeichnis

Grid - View 3 3

Grid - View 3

The Grid view can be called directly with the 3 key. This view is also called Multi-EPG.

In this view, the EPG is displayed graphically and is intended to provide an overview of the programs are currently running and those that will be broadcast on the various stations.

Current or planned recordings are indicated by a red bar above the event. The bar also shows the pre and post padding. A button can be set in the setup menu item „Key for the Grid“. By default, channels that were selected in the setup menu item „Select bouquet“ for scanning or to be displayed are available.



Explanation of the keys

Program a timer or edit an existing timer

Create and display a search from the selected event. This feature can also be used to quickly search for replays

Jumps to the program in the Guide - View 1

Switch to the File Database Editor

Scroll backwards by page

Scroll forward page by page

Jumps back 24 hours from the marked event

Jumps forward 24 hours from the marked event

Jump to Prime time

Jumps to the current broadcast

Switches to the selected channel

OK - Long => Opens a window to select another bouquet

Display the extended information of the selected program

Jump to View 1 - Guide

Jump to View 2 - Overview

Jump to View 4 - Next event

Jump to View 5 - Timer

Jump to View 6 - Search

Calls up the SmartEPGvu+ menu

Exit

If the „Set timer“ button, i.e. the record button, is pressed, the display of the first line in the legend changes as follows:

Program a timer or edit an existing timer

Block or unblock timers

Change timer type (R, P or M timer) - more detailed explanation under Timer types

Delete the marked timer

Create and display a search from the selected event. This feature can also be used to quickly search for replays

Jumps to the program in the Guide - View 1

Switch to the File Database Editor

From:
https://nayal.de/ -

Permanent link:
https://nayal.de/doku.php/oz:sicht3

Last update: **2024/01/14 19:39**